

SPECIFICATIONS

Torque Specifications

Description	Nm	lb-ft	lb-in
Driver air bag module bolts	7	—	62
Front impact severity sensor bolt	12	9	—
Passenger air bag module bolts	11	8	—
Restraints control module bolts	12	9	—
Seat position sensor bolts	6	—	53

Torque Specifications (Continued)

Description	Nm	lb-ft	lb-in
Seat side air bag module bracket to seat side air bag module nuts	6	—	53
Seat side air bag module and bracket to seat backrest bolts	10	—	89
Side impact sensor severity bolts	11	8	—
Seat track assembly nuts	36	27	—